

# ANKLE BRACE TRANSITION PROTOCOL

*A Quicker, More Functional Transition*



**WALKING BOOT**



## QUICKER TRANSITION

- The Ultra CTS is an active extension of your walking boot transition protocol.
- The Ultra CTS unloads/offloads the ankle which reduces impact that causes weight bearing discomfort. This unloading feature is great for patients or athletes who need to return to activity quickly after injury.

## MORE FUNCTIONAL TRANSITION

- The dual hinged-cuff upright design of the Ultra CTS provides maximum lower leg and ankle compression/stabilization.
- Restricts excessive ankle inversion and rotation to treat both classic and syndesmotic ankle injuries.
- Full unrestricted plantar and dorsiflexion promotes active rehabilitation to quickly regain ankle range of motion and muscle strength.
- Detach the upper cuff section and transition to a low profile rehab or sports brace.

MEASURE ANKLE CIRCUMFERENCE FOR PRECISE SIZING

SMALL / MEDIUM  
14in (35½cm) & below

LARGE / X-LARGE  
14in (35½cm) & above



Only Two Sizes Needed  
Fits Left or Right Ankle  
Extra Long Straps Available



# A FUNCTIONAL TRANSITION STARTS WITH THE ULTRA CTS®



**LACE-UP**



**ULTRA CTS®**

Suggested HCPCS Code	L1902	L1971
Fits Either Ankle	✓	✓
Full Plantar and Dorsiflexion ROM		✓
Maximum Tibia/Fibula Compression & Stabilization		✓
Unloads the Ankle to Reduce Weight Bearing Discomfort		✓
Quick & Easy Application		✓
Braces Acute Ankle Injuries		✓
Braces Syndesmotic Ankle Injuries		✓
2 Braces in 1 (See Details Below)		✓



◀ **Detach the PerformaFit® upper cuff section for a low-profile rehab or sports ankle brace.**